

ULTRASONIC SENSORS

US18-PA-5-N03-IH = Ultrasonic M18 axial - 4-20 mA analogue - M12	95B040020
US18-PA-5-N03-OH = Ultrasonic M18 axial - PNP/NPN- M12	95B040000
US18-PA-5-N03-VH = Ultrasonic M18 axial - 0-10V analogue - M12	95B040040
US18-PL-5-N03-NH = Ultrasonic square right angle mounting - NPN - M12	95B040140
US18-PL-5-N03-PH = Ultrasonic square right angle mounting - PNP - M12	95B040150
US18-PR-5-N03-IH = Ultrasonic M18 radial - 4-20 mA analogue - M12	95B040030
US18-PR-5-N03-OH = Ultrasonic M18 radial - PNP/NPN- M12	95B040010
US18-PR-5-N03-VH = Ultrasonic M18 radial - 0-10V analogue - M12	95B040050
US30-PR-5-N13-IH = Ultrasonic M30 radial 1000mm - 4-20 mA analogue - M12	95B040060
US30-PR-5-N13-OH = Ultrasonic M30 radial 1000mm- PNP/NPN- M12	95B040100
US30-PR-5-N13-VH = Ultrasonic M30 radial 1000mm - 0-10V analogue - M12	95B040070
US30-PR-5-N23-IH = Ultrasonic M30 radial 2000mm - 4-20 mA analogue - M12	95B040080
US30-PR-5-N23-OH = Ultrasonic M30 radial 2000mm- PNP/NPN- M12	95B040110
US30-PR-5-N23-VH = Ultrasonic M30 radial 2000mm - 0-10V analogue - M12	95B040090
US50-PR-5-N43-IVH = Ultrasonic radial 8000mm - analogue output - M12	95B040130
US50-PR-5-N43-OH = Ultrasonic radial 8000mm - PNP/NPN - M13	95B040120

CABLES

CS-A1-02-B-NC = M12 4-p axial PG	G5085002
CS-A1-02-G-03 = M12 4-p axial 3m	95A251380
CS-A1-02-G-05 = M12 4-p axial 5m	95A251270
CS-A1-02-G-10 = M12 4-p axial 10m	95A251390
CS-A1-02-O-05 = M12 4-p axial 5m CEI 2034-01	95A251710
CS-A1-02-O-10 = M12 4-p axial 10m CEI 2034-01	95A251090
CS-A1-02-R-02 = M12 4-p axial 2m PUR	95A251540
CS-A1-02-R-05 = M12 4-p axial 5m PUR	95A251560
CS-A1-02-U-03 = M12 4-p axial 3m UL 2464	95ASE1120
CS-A1-02-U-05 = M12 4-p axial 5m UL 2464	95ASE1130
CS-A1-02-U-10 = M12 4-p axial 10m UL 2464	95ASE1140
CS-A1-02-U-15 = M12 4-p axial 15m UL 2464	95ASE1150
CS-A1-02-U-25 = M12 4-p axial 25m UL 2464	95ASE1160
CS-A1-03-G-03 = M12 5-p axial 3m	95ACC2110
CS-A1-03-G-05 = M12 5-p axial 5m	95ACC2120
CS-A1-03-G-10 = M12 5-p axial 10m	95ACC2140
CS-A1-03-U-03 = M12 5-p axial 3m UL 2464	95ASE1170
CS-A1-03-U-05 = M12 5-p axial 5m UL 2464	95ASE1180
CS-A1-03-U-10 = M12 5-p axial 10m UL 2464	95ASE1190

CS-A1-03-U-15 = M12 5-p axial 15m UL 2464	95ASE1200
CS-A1-03-U-25 = M12 5-p axial 25m UL 2464	95ASE1210
CS-A1-03-U-50 = M12 5-p axial 50m UL 2464	95A252700
CS-A2-02-B-NC = M12 4-p radial PG	G5085003
CS-A2-02-G-03 = M12 4-p radial 3m	95A251360
CS-A2-02-G-05 = M12 4-p radial 5m	95A251240
CS-A2-02-G-10 = M12 4-p radial 10m	95A251260
CS-A2-02-O-05 = M12 4-p radial 5m CEI 2034-01	95A251690
CS-A2-02-O-10 = M12 4-p radial 10m CEI 2034-01	95A251700
CS-A2-02-R-02 = M12 4-p radial 2m PUR	95A251550
CS-A2-02-R-05 = M12 4-p radial 5m PUR	95A251570
CS-A2-12-G-03 = M12 4-p radial 3m LED	95A251400
CS-A2-12-G-05 = M12 4-p radial 5m LED	95A251350
CS-A2-12-G-10 = M12 4-p radial 10m LED	95A251370

MOUNTS/STANDS

SP-40 = Tubular mounting bracket	95ACC1370
ST-1218 = M12/M18 mounting brackets	95ACC3340
ST-1830 = M18/M30 mounting brackets	95ACC3350
ST-30MM = US50 stainless steel bracket	95ACC7830
ST-30SC = US50 assial bracket	95ACC7820
ST-5011 = M18 mounting bracket short	95ACC5240
ST-5012 = M18 mounting bracket long	95ACC5250
ST-5017 = M18 mounting bracket	95ACC5270
ST-S67Y S67Y MOUNTING KIT	95ACC8160