

## **POWERSCAN 9100 SERIES**

PowerScan D9100 RS-232 KIT (Kit inc. PD9130, CAB-434)

PD9130-K2

PowerScan D9100 USB KIT 9 (Kit inc. PD9130, CAB-524)

PD9130-K1

PowerScan M9100 433 RB RS-232 KIT EU (Kit inc. PM9100-433RB, BC9030-433, CAB-433, 8-0935, 6003-0940)

PM9100-433RBK20

PowerScan M9100 433 RB USB KIT EU (Kit inc. PM9100-433RB, BC9030-433, CAB-438, 8-0935, 6003-0940)

PM9100-433RBK10

PowerScan M9100 910 RB USB KIT US (Kit inc. PM9100-910RB, BC9030-910, CAB-438, 8-0935, 6003-0941)

PM9100-910RBK10

PowerScan M9100/D Display/4-Key Keypad, 433 RB RS-232 KIT EU (Kit inc. PM9100-D433RB, BC9030-433, CAB-433, 8-0935, 6003-0940)

PM9100-D433RBK20

PowerScan M9100/D Display/4-Key Keypad, 433 RB USB KIT EU (Kit inc. PM9100-D433RB, BC9030-433, CAB-438, 8-0935, 6003-0940)

PM9100-D433RBK10

PowerScan M9100/D Display/4-Key Keypad, 910 RB RS-232 KIT US (Kit inc. PM9100-D910RB, BC9030-910, CAB-433, 8-0935, 6003-0941)

PM9100-D910RBK20

PowerScan M9100/D Display/4-Key Keypad, 910 RB USB KIT US (Kit inc. PM9100-D910RB, BC9030-910, CAB-438, 8-0935, 6003-0941)

PM9100-D910RBK10

PowerScan PBT9100 REM.BATT RS-232 KIT EU (Kit inc. PBT9100-RB, BC9030-BT, CAB-433, 8-0935, 6003-0940)

PBT9100-RBK20EU

PowerScan PBT9100 REM.BATT RS-232 KIT US (Kit inc. PBT9100-RB, BC9030-BT, CAB-433, 8-0935, 6003-0941)

PBT9100-RBK20US

PowerScan PBT9100 REM.BATT USB KIT EU (Kit inc. PBT9100-RB, BC9030-BT, CAB-438, 8-0935, 6003-0940)

PBT9100-RBK10EU

PowerScan PBT9100 REM.BATT USB KIT US (Kit inc. PBT9100-RB, BC9030-BT, CAB-438, 8-0935, 6003-0941)

PBT9100-RBK10US

PowerScan PBT9100, Bluetooth, Linear Imager, Removable Battery

PBT9100-RB

PowerScan PD9130, Linear Imager, Multi-Interface	PD9130
PowerScan PM9100 910 RB RS-232 KIT US (Kit inc. PM9100-910RB, BC9030-910, CAB-433, 8-0935, 6003-0941)	PM9100-910RBK20
PowerScan PM9100, 433 MHz, Linear Imager, Display/16-Key, RB	PM9100-DK433RB
PowerScan PM9100, 433 MHz, Linear Imager, Display/4-Key , RB	PM9100-D433RB
PowerScan PM9100, 433 MHz, Linear Imager, Removable Battery	PM9100-433RB
PowerScan PM9100, 910 MHz, Linear Imager, Display/16-Key, RB	PM9100-DK910RB
PowerScan PM9100, 910 MHz, Linear Imager, Display/4-Key , RB	PM9100-D910RB
PowerScan PM9100, 910 MHz, Linear Imager, Removable Battery	PM9100-910RB

## **BASE STATION**

BC9030 Base Station/Charger, 433 MHz, Multi-Interface (RS-232, USB and KBD Wedge)  
BC9030-433

BC9030 Base Station/Charger, 910 MHz, Multi-Interface (RS-232, USB and KBD Wedge)  
BC9030-910

BC9030 Base/Charger BT Multi-Interface (RS-232, USB and KBW)  
BC9030-BT

BC9130 Base Station/ Dual Charger, 433 MHz, Multi-Interface (RS-232, USB and KBD Wedge), Spare Battery Slot  
BC9130-433

BC9130 Base Station/ Dual Charger, 910 MHz, Multi-Interface (RS-232, USB and KBD Wedge), Spare Battery Slot  
BC9130-910

BC9130 Base/Dual Charger BT Multi-Interface (RS-232, USB and KBW), Spare Battery Slot  
BC9130-BT

BC9160 Base Station/Dual Charger, 433 MHz, Multi-Interface (RS-232, USB, KBD Wedge and RS485), Spare Battery Slot  
BC9160-433

BC9160 Base Station/Dual Charger, 910 MHz, Multi-Interface (RS-232, USB, KBD Wedge and RS485), Spare Battery Slot  
BC9160-910

BC9180 Base Station/Dual Charger, 433 MHz, Ethernet  
BC9180-433

BC9180 Base Station/Dual Charger, 910 MHz, Ethernet  
BC9180-910

BC9180 Base/Dual Charger BT Ethernet, Spare Battery Slot  
BC9180-BT

## **BATTERIES/BATTERY CHARGERS**

Battery Charger, 4-Slot, MC-9000; (requires the 90ACC0350 power supply)

MC-P090



BATTERY CHARGER, C-9000

CHR-P090

BATTERY PACK, REMOVABLE, RBP-9001, 3350MAH, PLUS

RBP-PM91

Battery Pack, Removable, RBP-9001, 3350mAh, Plus, Locking System

RBP-PM91-LK

BATTERY PACK, REMOVABLE, RBP-9001, BLACK

RBP-PM91-BK

## CABLES

CAB-438 USB Type A Straight	CAB-438
Cable, IBM USB, 12 VDC, Powers USB, Coiled, 15 ft, CAB-486	CAB-486
Cable, KBW, PS/2, Coiled, CAB-437, 9 ft.	CAB-437
Cable, KBW, PS/2, External Power, Straight, CAB-442	CAB-442
Cable, KBW, PS/2, Laptop, Coiled, 3.6 m, CAB-463	CAB-463
Cable, KBW, PS/2, PWR, Coiled 3.6 m, CAB-462	CAB-462
Cable, KBW, PS/2, Straight, CAB-436, 6 ft.	CAB-436
Cable, RS-232 PWR, 25P, Female, Coiled, 3.6 m, CAB-474	CAB-474
Cable, RS-232 PWR, 25P, Female, Coiled, 7.6 m, CAB-477	CAB-477
Cable, RS-232 PWR, 9P, Female, Coiled, 3.6 m, CAB-459	CAB-459
Cable, RS-232 PWR, 9P, Female, Coiled, CAB-434, 8 ft.	CAB-434
Cable, RS-232 PWR, 9P, Female, Straight, 3.2 m, CAB-501	CAB-501
Cable, RS-232 PWR, 9P, Female, Straight, CAB-433, 6 ft.	CAB-433
Cable, RS-232, 25P, Female, Coiled, CAB-471, 10 ft.	CAB-471
Cable, RS-232, 25P, Male, CBX800 Power Off Terminal, Coiled, 12 ft.	CAB-512
Cable, RS-232, 25P, Male, CBX800, External Power, Coil, 12 ft	CAB-509
Cable, RS-232, 25P, Male, Coiled, CAB-472, 10 ft.	CAB-472
Cable, RS-232, 9D, Female, POT, Coiled, 25 ft, 90A052014, CAB-479	CAB-479
Cable, RS-232, 9P, Female, Straight, CAB-350 (Power Supply available on pin 9 of the connector or through external power supply), 6 ft.	

	90A051230
Cable, RS-232, 9P, Male, Coiled, 3.6 m, CAB-456	CAB-456
Cable, RS-232, RJ10 Magellan Bi-Optic AUX Port, Coiled, 3.6 m, CAB-461, 12 ft.	CAB-461
Cable, USB, Type A, Coiled, POT, CAB-524, 8 ft.	CAB-524
Cable, USB, Type A, Coiled, TPUW, CAB-550, 2.4m	CAB-550
Cable, USB, Type A, External Power, Coiled, CAB-441, 8 ft.	CAB-441
Cable, USB, Type A, External Power, Straight, CAB-440, 8 ft.	CAB-440
Cable, USB, Type A, Straight, 3.6 m, CAB-465	CAB-465
CS-A1-01-G-03 = M12 3-p axial 3m	95A251290
CS-A1-01-G-05 = M12 3-p axial 5m	95A251300
CS-A1-01-G-10 = M12 3-p axial 10m	95A251340
EXTENSION INTERFACE CABLE - INDUSTRIAL	90A052329
RS232 cable for WWS750 scanner, 9P female, 6ft	CAB-448

## CASES/HOLSTERS



Holder, Desk/Wall Mount

HLD-P080



Holster, Universal, HLS-8000

HLS-P080



Protective Case/Belt Holster, PC-9000

PC-P090

## MISCELLANEOUS

FIELDBUS CONVERTER, ETH IP, INDUSTRIAL

FBC9080-N200

FIELDBUS CONVERTER, PROFINET, INDUSTRIAL

FBC9080-N100



Replaceable Window, Plastic, RWB-9300

RWD-P093-PL

Star System USB Industrial Dongle 433 MHz

SD9030-433-A

Star System USB Industrial Dongle 910 MHz

SD9030-910-A

## MOUNTS/STANDS



Industrial Take Up Reel

7-0404



STAND, HANDS-FREE, STD-9000

STD-P090



Vehicle Mount Kit, VMK-9000

VMK-P090



## **POWER SUPPLIES/CORDS**

ADAPTER, POWER PLUG, AUSTRALIA	90ACC0309
ADAPTER, POWER PLUG, EURO, 2 PIN	90ACC0307
ADAPTER, POWER PLUG, UK	90ACC0308
ADAPTER, POWER PLUG, US/JAPAN	90ACC0306
Power Adapter, 12V DC, AC/DC Regulated, RoHS (Requires Power Cord - 6003-XXXX)	8-0935
Power Cord, 120V, US, Twist & Lock	6003-0932
Power Cord, 220V, Australia	6003-0925
Power Cord, 220V, Italy/Chile	6003-0924
Power Cord, 240V, UK	6003-0923
Power Cord, 2-Pin, EU	90ACC1885
Power Cord, 2-Pin, UK	90ACC1887
Power Cord, 2-Pin, US	90ACC1886
Power Cord, AC, IEC/EU	6003-0940
Power Cord, Euro Monitor	6003-0931
Power Cord, IEC C13, Argentina	6003-0926
Power Cord, IEC C13, Brazil (For use with 8-0935)	6003-0942
Power Cord, IEC C13, China	6003-0935
Power Cord, IEC C13, Korea	6003-0930
Power Supply, 12VDC, US, PG12-10P35-US (includes power cord 90ACC1886)	90ACC1920

Power Supply, 5VDC, includes 2 pin power cord adapter, no power cord

90ACC0287

RS,9P, SOCKET, POT@4, COIL, 3.6M, SH5327

CAB-541

US Power Cord, 110V, US, Standard

6003-0941